

Instructions for Hot Dog Machine Operation



Setup:

- Place Hot Dog Machine on a secure tabletop.
- Plug machine into a 120 Volt, 2,200 Watt, 7 Amp circuit. Be sure electrical source is sufficient to properly power machine.

Making Hot Dogs:

- Turn ON the power switch.
- Set the temperature control knob to your desired cooking temperature. Heating indicator light will turn on as temperature rises. Indicator light will turn off when element reaches the desired temperature.
- Machine takes about 30 minutes to cook frozen hot dogs and 20 minutes to cook room temperature hot dogs.
- Dual Controls: Front Rollers and Rear Rollers can be set to different temperatures. One can be set to higher temperatures to cook the hot dogs while the other is set to lower temperature to warm the hot dogs.
- Turn OFF the power switch when you are done cooking.

Potential Problems:

- DO NOT try to clean the unit with water, or immerse motor base in water. This may cause serious damage!
- NEVER place anything other than hot dogs on the unit.
- Unplug machine from outlet when not in use and when cleaning.
- Keep out of reach of children.
- Be sure to have drip tray in place when using the rollers to cook hot dogs.
- Not intended to be used by young children.